



## 1. Product Name

MacroTint and MiniTint

## 2. Manufacturer

WOOD KOTE PRODUCTS INC  
8000 NE 14<sup>th</sup> Pl (97211)  
PO Box 17192  
Portland OR 97217  
Tel: (800) 843-7666 (USA & Canada)  
Tel: (503) 285-8371  
Fax: (503) 285-8374  
[info@woodkote.com](mailto:info@woodkote.com)  
[www.woodkote.com](http://www.woodkote.com)

## 3. Product Description

### BASIC USE

MacroTint and MiniTint are intended for professional use only. These are hand-held devices designed for extremely accurate measurement and dispensing of liquid colorants. They may be used to accurately measure and dispense any liquid colorant, flattening agent or additive.

### ADVANTAGES

- Accurate
- Durable
- Portable

### COMPOSITION & PROPERTIES

MacroTint and MiniTint are machined from aircraft-grade aluminum, anodized and laser etched. Calibration bar attached with stainless steel set screws. Cylinder bore is within 0.003 inches of the piston diameter. Solvents commonly associated with interior wood finishes should not affect the anodized surfaces.

### TYPES

MacroTint has a maximum dispensing volume of 5-fl oz (148 ml) and is calibrated in increments of 1/4 fl oz (7,4 ml).

MiniTint has a maximum dispensing volume of 1-fl oz (29,6 ml) and is calibrated in increments of 1/48 fl oz (0,6 ml).

### SIZES

MacroTint is sold in 5-fl oz (148 ml) size and MiniTint is sold in 1-fl oz (29,6 ml) size (see types).

## 4. Technical Data

### PHYSICAL PROPERTIES

Weight:

MacroTint 34 oz (964 gm)

MiniTint 6.2 oz (175,8 gm)

## 5. Installation

No installation is required. MacroTint and MiniTint are ready to use out of the package. Hold the device upright with the measurement numbers facing toward you. Grasp the piston at the bottom and turn until the calibration bar is aligned over the measurement numbers. Pull the piston down until the point at the end of the calibration bar reaches the desired increment, and then turn the piston 1/4 of a turn to lock it in place. Place the device on a horizontal surface and fill the cylinder space with the appropriate liquid up to the top rim, immediately pour the liquid into the proper receptacle while turning the piston to align the calibration bar over the measurement numbers. Push the piston to the top of the cylinder. Liquid remaining on the piston head should be removed with a metal scraper.

### CLEAN UP

MacroTint and MiniTint should be cleaned after each usage. The piston should be removed from the cylinder and all surfaces should be cleaned with a soft cloth and the proper solvent. Colorants should be removed from the devices with LaqThin T-99A (lacquer thinner). Other materials may best be removed with alternative solvents such as mineral spirits or detergent and water.



## 6. Availability & Cost

### AVAILABILITY

MacroTint and MiniTint are available through recognized Wood Kote retailers or directly from the manufacturer. A list of stocking dealers is available from the manufacturer and can be found on the manufacturer's web site.

### COST

Cost information is available from recognized Wood Kote retailers or from the manufacturer.

## 7. Warranty

MacroTint and MiniTint are warranted to be free from defects in materials and workmanship. Under normal usage and conditions these products should perform indefinitely. These products may be purchased for inspection and trial usage with a 60-day money back guarantee. Contact the manufacturer for complete details and return policy.

## 8. Maintenance

### ADJUSTMENT

From time to time the calibration bar on a MacroTint or MiniTint may become bent and lack sufficient friction to hold the cylinder in place. This may be corrected by removing the 2 stainless steel set screws that attach the calibration bar, very gently bending the bar in a slight arc in the direction of the piston and then re-attaching it.





## 9. Technical Services

MacroTint or MiniTint should not require technical service or assistance. Contact the manufacturer if you have questions or require additional information. The manufacturer provides starting tint formulas, which are available on the manufacturer's web site.

## 10. Filing Systems

- Wood Kote—Product Catalog
- Additional product information is available from the manufacturer.
- [www.woodkote.com](http://www.woodkote.com)